

# SUPATX FIN INSTALL INSTRUCTIONS

TO INSTALL YOUR SUP FIN YOU WILL NEED THE FOLLOWING:

- YOUR SUPATX FIN
- FIN SCREW AND PLATE (already in fin slot)
- SCREW DRIVER

First unscrew the fin screw from the plate and set aside for later. A channel inside the fin box allows the plate to be slid anywhere inside the fin box to accommodate all fins and your own preferences.

Using a screwdriver, slide the plate to the front of the fin box for now.

Now for the fin. located at the back of the fin is a metal pin. This pin will need to be inserted into the opening in the fin slot. Push in gently until the pin has gone into the channel and then slide the fin to the back of the fin box. It is easiest if you keep the front of the fin out of the fin box at an angle while sliding the fin back.

Once the fin is pushed back, lower the front of the fin into the fin box. This may take some gentle pressure. Once the fin is pressed into position, you will need to slide the screw plate using a screwdriver so that it lines up with the fin hole at the front of the fin. If you slide it too far, simply raise the tail of the board until the plate comes back. Take the screw and insert it into the fin hole until threaded into the plate. Finally screw it into place using the screwdriver until just snug. Over tightening can damage the board severely.

